



CREATOR





31072




[LEGO.com/creator](https://www.lego.com/creator)

3 in 1
3 en 1
3 em 1
3 az egyben
3合1




1x

1





2





1x

2







3




4





2x




5





4





6








9







10








11




12






13




14





1x

15




1x



1x


16






1x

17



1x


18






1x

19




20





1x

21




1x



1x


22





1x

23




1x



1x


24






1x

25



1x


26







1x

27




28





2x

29




1x



2x

30







2x



2x

31




1x



1x

32






1x





2x

33

1




2





1x

34





1x





1x


35





36





7



Customer Service
Kundenservice
Service Consommateurs
Servicio Al Consumidor

LEGO.com/service or dial



: 00800 5346 5555
: 1-800-422-5346

